

## Compliance Information



This symbol on the product indicates that this product shall not be treated as household waste. Instead it shall be sent to the applicable collection point for the recycling of electronic equipment.

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health. For more information about the recycling of this product, please contact your local city office.

## Cautions

Please read all warnings for your safety and optimal user experience. Please read and follow these instructions carefully and retain for your records.

1. Do not disassemble or throw into fire or water.
2. Do not expose to extreme weather conditions.
3. Do not use this product if you observe visible defects.
4. Do not short circuit the product or store it in a receptacle where it may be short circuited by other metallic or conductive objects.
5. Do not operate the product if it has been wet or otherwise damaged, to prevent against electric shock, explosion and/or injury.
6. Never attempt to dismantle the unit.
7. Children should be supervised to ensure that they do not play with the product.
8. Do not use if broken, damaged, or exposed to liquids.
9. Not to be used in extremely high ambient temperatures.
10. Do not use with damaged or faulty accessories.
11. Do not place near any sources of heat, open flame, or liquid.
12. Do not place close to a magnetic strip or strip card as it could cause magnetic failure.
13. Please keep charger a safe distance of at least 80cm from any implantable medical devices to avoid medical device interference.
14. In the case of the device overheating, place disconnect immediately.

## Disclaimer

Cygnett and the Cygnett logo are trademarks of Cygnett Pty Ltd. Other brands and product names are trademarks or registered trademarks of their respective holders. Made in China.

### Cygnett Pty Ltd

858 Lorimer Street, Port Melbourne,  
Victoria, 3207, Australia

### Cygnett USA Inc

3838 W Carson St, Ste 220,  
Torrance, CA 90503

### Cygnett NZ Ltd

Level 9, 45 Queen Street,  
Auckland 1010

### Cygnett UK Ltd

71-75 Shelton St, London,  
WC2H 9JQ

### Cygnett EU

Redwood Fulfillment,  
Sikkel 17, 3274 KK Heinenoord,  
The Netherlands

### Cygnett EU Authorised Representative

24hour-AR, Van Nelleweg 1, 3044  
BC Rotterdam, The Netherlands  
compliance@24hour-ar.com

CYGNETT®

ENCORE



2-in-1 Foldable Magnetic  
Wireless Charger

User Manual


### Want to stay in touch?

Scan below to receive exclusive deals, access early product launches, and get all the latest from Cygnett.



### Description of Parts

- A** 15W Wireless Charging Pad
- B** Apple Watch Puck / Apple AirPods
- C** USB-C Input



### Installation Instructions

#### Charging Your Devices Wirelessly

Connect the included USB-C cable into a compatible 30W wall charger for optimal charging, and the other end to the USB-C input (C). Place your wireless charging device on the magnetic wireless output (A).

#### Charge Your Apple Watch

Place your Apple Watch on the wireless output 2 (B). Your Apple Watch should begin to wirelessly charge.

#### Charge Your AirPods

Place your AirPods on the magnetic wireless output (A) or on the wireless output 2 (B). Please note compatible AirPods cases for charging from output 2 (B) include AirPods 3 / AirPods 4 / AirPods Pro 2 / AirPods Pro 3 / Magsafe charging case.

### Product Specifications

|                     |                                                  |
|---------------------|--------------------------------------------------|
| <b>Name</b>         | Encore 2-in-1 Foldable Magnetic Wireless Charger |
| <b>Item Number</b>  | CY6054NFWIR                                      |
| <b>Input(s)</b>     | 5V/3A, 9V/3A                                     |
| <b>Output(s)</b>    | <b>Output 1:</b> 15.0W<br><b>Output 2:</b> 2.5W  |
| <b>Total Output</b> | 17.5W Max.                                       |

#### CAUTION:

The Encore 2-in-1 Foldable Magnetic Wireless Charger uses inductive charging, do not place metallic objects such as coins, keys, metallic cases or metal foil on top of the charging pad.

